



RINGBROTHERS

E4829 Hwy 14 • Spring Green, WI 53588 • 608.588.7399 • www.ringbrothers.com • info@ringbrothers.com

Warning

- Disconnect battery before installation – Failure may result in electrical damage
- Do not allow charging lug to come in contact with the chassis or body – Electrical damage may occur

Panel Mounting

- Cut out template on provided drawing and use as a stencil
- Center punch hole centers
- Cut two holes with a 1-3/8" Bi-metal hole saw
- Finish trimming by hand
- De-burr all sharp edges
- Paint all exposed metal prior to installing
- Assemble Charge Port into your panel as shown on provided drawing
- Apply blue Loc-Tite to all threads prior to tightening

Male Lug Assembly (From charge)

- Slide plastic handle over cable then strip approximately $\frac{3}{4}$ " of cable insulation
 - Note: works with 1 or 2 gauge cables
- Insert the exposed wire completely into charging lug and secure with the with the socket screw
- Slide the plastic handle over the male charging lug and secure with the #8-32 socket head cap screw