



E4829 Hwy 14 • Spring Green, WI 53588 • 608.588.7399 • [www.ringbrothers.com](http://www.ringbrothers.com) • [info@ringbrothers.com](mailto:info@ringbrothers.com)

## 99000-9415 Universal Carbon Fiber Hood Scoop

### Preparation instructions for carbon fiber:

- Clean scoop with acetone
- Hand sand with 320 grit sand paper—**DO NOT over sand!**
- Clean scoop with acetone again
- Brush on 4 to 5 coats of clear coat with a foam brush
- Once clear coat is completely dry, sand clear like you would primer
- Once smooth, clean once more with acetone and then spray with clear coat to desired finish.

Thank you for purchasing a Ringbrothers Universal Carbon Fiber Hood Scoop.

---